



Light Control Connection Diagram






Motor "M-"

CH4

-CH1



When No. 3 and No.4 slide switch are on the right, it indicates that the drag brake force is set to 100%.


The receiver automatically enters the binding state once it is powered on.


Press the BIND key to turn on the transmitter (FS-HW-G4P) and allow it to enter its binding state. Here, G.LED flashes quickly, and operator releases the

When the receiver is powered on and waits for 1 second, it will automatically enter the binding state if it is not connected;


























If incorrect, the car will move instability.

