

Before strating:

1、 You need these tools:

tweezers、 long nose pliers、 side cutter、 PH0/PH1 cross screwdriver、 1.5mm&2.5mm hex wrench 、 double side tape、 scissors、 sandpaper.

2、 Finished painting before assembling (before painting,you should remove burrs and clean the ABS patrs) .

